



# PIPE BRACE CONNECTOR

**DESLAURIERS PIPE BRACE CONNECTOR** allows standard pipe braces to be used with Deslauriers Column Forms.

Simply replace the form connector with the Pipe Brace Connector, and bolt to a horizontal flange on the column form. Installation of each bracket requires two sets of 1/2" dia. x 2" coil bolt and nut. Pipe brace connecting bolt provided by others.

**CAT#: HDS-PBC** --Sale

**CAT#: HD-PBC** --Rental, rentals are for a minimum of 28 days



# DOUBLE PIPE BRACE CONNECTOR

**DESLAURIERS DOUBLE PIPE BRACE CONNECTOR** can be used to erect and plum column forms. It can also be used to brace from a capitol form down to a column form when pouring a column and capitol monolithically.

Merely replace the form connector with the Deslauriers Double Pipe Brace Connector and bolt to a horizontal flange on the column form. Installation of each bracket requires two sets of 1/2" dia. x 2" coil bolt and nut. Pipe brace and pipe brace connecting bolt provided by others.

**CAT#: HDS-PBC-D** --Sale

**CAT#: HD-PBC-D** --Rental, rentals are for a minimum of 28 days

