



CONTROLLED LOW STRENGTH MATERIAL SAMPLE KIT (CLSM)

The CLSM Sample Kit contains four (4) water proof specimen cylinders to make 3" dia x 6" high specimens. Each cylinder contains an engineered liner which minimizes friction, allowing specimen to easily separate from cylinder. The cylinders also contain a bottom insert which helps eliminate vacuum and protects bottom edges of specimen from damage.

- Comes ready to use
- Requires no special tools-no knives!
- No cutting
- No damage to the specimens



INSTRUCTIONS FOR USE:

- Place CLSM into cylinders.
- Rod as necessary to remove air.
- Strike off and attach lids.

CAT#: CLSM --3" dia x 6" high specimens, 4 per carton

CAT#: CLSM-4 --4" dia x 8" high specimens, 1 per carton

CAT#: CLSM-6 --6" dia x 12" high specimens, 1 per carton

INSTRUCTIONS FOR STRIPPING:

- Remove cylinders from transport container and remove the lid.
- Turn upside down, with the bottom up.
- Apply air to the hole to eliminate vacuum-something as small as a bike pump will work.
- The cylinder will rise, allowing for easy removal.
- Remove the engineered liner and the specimen is ready for testing.



ENGINEERED
LINER



BOTTOM
INSERT



APPLYING AIR
TO CYLINDER



CYLINDER RELEASING
FROM SPECIMEN

